


Sanitant Station Filter

This filter connects to the sanitant station and protects the MAST system from particles that could be present in the sanitant. It also serves as a prefilter to protect the sample pilot sterile filters. The sanitant station filter is easy to install and remove with valved quick disconnect and should be replaced monthly.



FEATURES

- Disposable
- Quick to remove and replace
- No spill connectors
- User friendly

SPECIFICATIONS

Measurements:

- Width: 1.6 in. (Max.)
- Height: 10.2 in.
- Depth: 1.6 in. (Max.)
- Weight: 0.2 lbs.

Utilities and/or Components Required:

- MAST sanitant station